



GENERIC PRINTER DRIVER SETTINGS

Should a printer profile or printer setting not exist for your specific model of printer, ILFORD recommends the following generic printer settings below.

1. PRESTIGE Gold Fibre Silk*, PRESTIGE Smooth Pearl & Gloss Paper 310gsm/290gsm PRESTIGE Smooth High Gloss, PRESTIGE Smooth Lustre Duo

Epson® Printers:	Media Type Print Quality Color Control	Epson Ultra Glossy or Premium Semigloss Photo Paper Photo or Best Photo Epson Vivid
Canon® Printers:	Media Type Print Quality Color Control	Photo Paper Plus Glossy High Auto
HP® Printers:	Media Type Print Quality Color Control	HP Advanced Photo Paper Best ColorSmart/sRGB or defaults
Lexmark® & Dell®:	Media Type Print Quality Color Control	Glossy Photo Paper Best Defaults

*Gold Fibre Silk media is recommended for use with Pigment Printers

2. PRESTIGE Smooth Fine Art Paper

Epson® Printers:	Media Type Print Quality Color Control	Epson Matte or Photo Quality Inkjet Paper Photo or Best Photo Epson Vivid
Canon® Printers:	Media Type Print Quality Color Control	High Resolution Paper High Auto
HP® Printers:	Media Type Print Quality Color Control	HP Premium Paper Normal or Best ColorSmart/sRGB or defaults
Lexmark® & Dell®:	Media Type Print Quality Color Control	Coated Paper Normal, Better or Best Defaults

ILFORD GALERIE

PROFESSIONAL INKJET PHOTO RANGE



GENERIC PRINTER DRIVER SETTINGS

Should a printer profile or printer setting not exist for your specific model of printer, ILFORD recommends the following generic printer settings below.

1. PREMIUM Lustre, PREMIUM Gloss, PREMIUM Lustre Duo

Epson® Printers: Media Type Epson Ultra Glossy or Premium Semigloss Photo Paper
Print Quality Photo or Best Photo
Color Control Epson Vivid

Canon® Printers: Media Type Photo Paper Plus Glossy
Print Quality High
Color Control Auto

HP® Printers: Media Type HP Advanced Photo Paper
Print Quality Best
Color Control ColorSmart/sRGB or defaults

Lexmark® & Dell®: Media Type Glossy Photo Paper
Print Quality Best
Color Control Defaults

2. PREMIUM Heavyweight Matt Paper

Epson® Printers: Media Type Epson Matte or Photo Quality Inkjet Paper
Print Quality Photo or Best Photo
Color Control Epson Vivid

Canon® Printers: Media Type High Resolution Paper
Print Quality High
Color Control Auto

HP® Printers: Media Type HP Premium Paper
Print Quality Normal or Best
Color Control ColorSmart/sRGB or defaults

Lexmark® & Dell®: Media Type Coated Paper
Print Quality Normal, Better or Best
Color Control Defaults